Job Page

This page allows you to view the status of current print jobs.

Active Job List (shown above)

The [Job] - [Active Job List] window provides the following information for up to 45 print jobs:

Item	Description
[Job Number]	Displays the print job identification number. Each print job that the printer receives is assigned a unique identification number.
[User Name]	If known, displays the owner of the print job.
[File Name]	Displays the name of the print file.
[Job Status]	Displays the current status of the print job ([Parsing], [Printing], [Cancel], [Pending or Abort]).
[Create Time]	Displays the time that the job was queued.
[Delete] button	Deletes the print job(s) that applies to the checked boxes.

Done Job List

The [Job] - [Done Job List] window provides the following information for up to 50 print jobs:

Item	Description
[Job Number]	Displays the print job identification number. Each print job that the printer receives is assigned a unique identification number.
[User Name]	If known, displays the owner of the print job.
[File Name]	Displays the name of the print file.
[End Time]	Displays the time that the printing is finished.
[Result]	Displays the result of the print job ([OK], [Error], or [Canceled]).
[Detail] button	Displays a screen containing details.

Done Job List (Detail)

The [Job] - [Done Job List] - [Detail] window provides the following information for the selected job:

Item	Description
[Job Number]	Displays the print job identification number. Each print job that the printer receives is assigned a unique identification number.
[User Name]	If known, displays the owner of the print job.
[File Name]	Displays the name of the print file.
[Delivery Type]	Displays the delivery method for the job ([Print], [Print and Hold], [Proof then Print], [IPP Print], [Secured Job], [Time Print], [Report Print or PC-FAX]).
[Create Time]	Displays the time that the job was queued.
[End Time]	Displays the time that the printing is finished.
[Result]	Displays the result of the print job ([OK], [Error], or [Canceled]).
[Back] button	Returns to the previous screen.