

REPORT

The machine settings, lists and reports related to fax can be printed.

[TX RESULT REPORT]	Prints the results of fax transmissions. For details, refer to the [Facsimile User's Guide] on the Documentation CD/DVD.
[RX RESULT REPORT]	Prints the results of fax receptions. For details, refer to the [Facsimile User's Guide] on the Documentation CD/DVD.
[ACTIVITY REPORT]	Prints the results of fax transmissions and receptions. For details, refer to the [Facsimile User's Guide] on the Documentation CD/DVD.
[MEMORY DATA LIST]	Prints the information for queued fax transmissions. For details, refer to the [Facsimile User's Guide] on the Documentation CD/DVD.
[MEMORY IMAGE PRINT]	Prints the information and a reduced first page of queued fax transmissions. For details, refer to the [Facsimile User's Guide] on the Documentation CD/DVD.
[FAVORITE LIST]	Prints a list of the destinations registered in the favorite list. For details, refer to the [Facsimile User's Guide] on the Documentation CD/DVD.
[SPEED DIAL LIST]	Prints a list of the destinations programmed for speed dialing. For details, refer to the [Facsimile User's Guide] on the Documentation CD/DVD.
[GROUP DIAL LIST]	Prints a list of the one-touch dialing groups. For details, refer to the [Facsimile User's Guide] on the Documentation CD/DVD.
[UTILITY MAP]	Prints the [UTILITY] menu and its settings.
[PS/PCL MENU MAP]	Prints [PS/PCL PRINT] menu and its settings.
[CONFIGURATION PAGE]	Prints a estimate of the percentage of toner remaining and the settings, information and status of this machine.
[PS FONT LIST]	Prints the PostScript font list.
[PCL FONT LIST]	Prints the PCL font list.
[DIRECTORY LIST]	Prints the directory list of the hard disk or a CompactFlash card.
