SCAN SETTING Menu

SCAN SETTING	IMAGE FORMAT
	CODING METHOD
	RESOLUTION
	DENSITY LEVEL
	SHARPNESS
	SCAN SIZE
	· · · · · · · · · · · · · · · · · · ·
	FILE SIZE
	SIARI KEY

	r -
~	
~	

Manufacturer's default settings appear in bold.

[IMAGE FORMAT]	Settings	[TIFF] / [PDF] / [JPEG]	
	 Select the default format for saving files with scan to e-mail operations. <i>PDF data can be opened in Adobe Acrobat Reader.</i> <i>TIFF files of images that have been scanned with the [COLOR or GRAY] setting cannot be opened with the Windows Picture and FAX Viewer, which is included with Windows XP as a standard component. These files can be opened with image-processing applications such as PhotoShop, Microsoft Office Documen Imaging or ACDsee.</i> 		
[CODING METHOD]	Settings	[MH] / [MR] / [MMR]	
	Select the de e-mail operat	fault compression method for scan to ions.	
	The compression ratio for these methods increases in the following order: [MH] > [MR] > [MMR].		
	These settings are available only if [BW Only] was selected for the color setting during the e-mail transmission.		
[RESOLUTION]	Settings	[150×150dpi] / [300×300dpi]	
	Select the default scanning resolution for scan to e-mail operations.		
[QUALITY PRIOR-	Settings	[MIX] / [TEXT] / [PHOTO]	
ITY]	Select the scan data quality that is used as a defa		
[DENSITY LEVEL]	Settings		
	Select the scan data density that is used as a default.		
[SHARPNESS]	Settings	(Soft)	
	Select the setting for [SHARPNESS].		

[SCAN SIZE]	Settings	[A5] / [A4] / [B5] / [STATEMENT] / [LET- TER] / [LEGAL]	
	Select the scanning size.		
	The default setting is [LETTER] on machines where [PTT SETTING] in the [USER SETTING] menu is set to [U.S.A] or [CANADA], and is [A4] if any other country is selected.		
[FILE SIZE]	Settings	[NO SPLIT] / [SPLIT]	
	Select whether or not to limit the size for scan data sent as e-mail attachments.		
	If [SPLIT] is selected, specify the maximum size between 1 and 10 Mb. If the data to be sent exceeds the maximum size allowed, the data is divided and sent as multiple attached files.		
	In order to receive multiple file attachments, an e-mail application compatible with divided transmissions is required.		
[START KEY]	Settings	[BW Only] / [COLOR or GRAY]	
	Select the operation performed when the Start key is pressed.		